



# Lenovo Yoga Tab 3 10 Battery Replacement

Use this guide to replace the battery.

Written By: Phanudej





## TOOLS:

- [Screwdriver, J000 Phillips Head](#) (1)
  - [Tweezers](#) (1)
-

## Step 1 — Back Cover



- Open the built-in kickstand.

## Step 2




- Remove the sticker located directly under the the built-in kickstand to reveal two 0.75 mm screws.
- Remove the microSD card slot cover.
- Using a Phillips head screwdriver, remove the three 0.75 mm screws.




## Step 3




- Orient the device so the screen is facing you.
  - Carefully insert the spudger along the seam between the screen and back cover and gently separate the back cover from the device frame.
  - Continue to detach the backplate from the frame by moving the spudger around the perimeter.
-  Some force will be required to detach the small plastic braces securing the backplate to the device.

## Step 4 — Battery



- Remove the 3 screws in the auxiliary port cover and lift the plastic piece.
- Carefully pull back the auxiliary module to move it out of the way.
- Remove the plastic block in front of the hinge.

## Step 5




- Use a spudger to pry the locking mechanism.

## Step 6



- Lift and pull to detach the battery compartment.

## Step 7



- Use tweezers to lift the tape covering the screw.
- ⓘ If using sharp-ended tweezers, try to avoid damaging the thin tape material.

## Step 8




- Use a small Phillips-head screwdriver to remove the screw.



## Step 9



- Open the cover and remove the battery.

 Pay careful attention to the battery's cable located on the opposite side during removal.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-27 06:37:46 AM.